

Popcorn Machine Instructions

Requirements

- Popcorn machine
- Trolley
- Popcorn kernels
- Popcorn bags
- Popcorn salt
- Oil
- Scoop
- Cleaning kit with bin bags

How to use:

- Plug in Popcorn machine
- Pour approx. 2/3 of plastic cup of kernels into saucepan
- Pour a good slurp of oil into the kernels, approx. 1-2 tablespoons.
- Turn on HEAT and LIGHT button
- Switch on TURN button
- Close lid on saucepan
- When popping is almost finished, turn saucepan upside down and shake
- Return saucepan to clip
- Shake popcorn salt over popcorn
- Use scoop to bag into bags

Notes

- Pre-cook extra popcorn for busy period and bag up
- When not cooking popcorn turn HEAT and TURN buttons to OFF
- If you have excess popcorn kernels: Move popped popcorn over the holes in the base of the machine, the kernels will fall through.

Cleaning

- Turn HEAT, LIGHT and TURN buttons off approx. 15 min before end of event (if possible)
- MUST WEAR GLOVES WHEN CLEANING – easy to cut fingers on edges.
- Clean from top to bottom (start with saucepan once cooled) work your way around glass, then base with kitchen wet wipes and paper towel
- Clean out draw underneath machine